

# Claro™ Application Instructions

## Step 1: Basecoat



Apply a tinted basecoat of Solido™, Alto™, or OmniCoat™.



Apply the basecoat in random, decorative trowel strokes.

# Claro™ Application Instructions

## *Step 1: Basecoat (continued)*



Finished basecoat. Allow to dry for 3 to 4 hours before proceeding.

## *Step 2: Coat of Claro™*



Apply the first coat of Claro™ on your basecoat.

# Claro™ Application Instructions

## *Step 2: Coat of Claro™ (continued)*



Apply Claro™ using random, decorative trowel strokes.



Finished Claro™.