

Anciano™ Application Instructions

Step 1: First Coat of Anciano™



Apply the first coat of Anciano™.



Apply this coat using random, decorative trowel strokes.

Anciano™ Application Instructions



Step 1: First Coat of Anciano™ (continued)



Finished first coat of Anciano™.

Step 2: Second Coat of Anciano™



Apply a second coat of Anciano™ using random, decorative trowel strokes.

Anciano™ Application Instructions

Step 2: Second Coat of Anciano™ (continued)



Finished second coat of Anciano™. Allow to dry 30 to 40 minutes before proceeding.

Step 3: Water Trowel



Lightly mist Anciano™ with water and trowel down.

Anciano™ Application Instructions



Finished Anciano™.